

Removes mains power to the socket after 30 minutes



30 Minute Rundown Timer

Reduces the risk of fires caused by heating appliances such as irons and hair straighteners being left accidentally on.

How to Use

Simply plug your iron, hair straightener or other appliance into the Timer socket and plug the Timer into a powered wall socket.



Press the button on the front of the Timer to enable the socket for 30 minutes and use your appliance. The lamp on the front will flash on and off while the Timer is counting down.

After 30 minutes the socket will be turned off and the lamp will stop flashing.

Press the button again to enable the socket on the Timer for another 30 minutes at any time.

Switch off at the mains socket or remove from the socket to remove power.

For indoor use only

For irons, hair straighteners and other appliances



Most suitable for irons and hair straighteners to reduce the risk of fire when accidentally left on.

Technical Information

Approved to the appropriate parts of BS5733, EN60730

Voltage: 220-250V AC 50Hz

Max. current: 13A

Max. power: 3kW

Product Code: ENER001

Indoor use only

RoHS
Compliant



Responsibly packaged
without plastic
Recyclable