

# **Standby Saver**

## **Questions & Answers**

### Q: What appliances is this product suitable for?

Answer: The Standby Saver is suitable for older tube televisions and appliances with standby modes that draw more than 40Watts of power in normal ON operation and more than 5watts in standby operation.

#### Q: Can I use it with my desktop computer?

Answer: You may be able to use it with your desktop computer if your monitor draws more than 40 watts in ON operation and less than 40 watts when the screen is blanked. Plug your Monitor into it and it will switch the power off when the computer is powered down or goes into a standby mode. When the computer is brought out of this low power mode ensure that you re-enable power to the monitor by pressing the green button.

# Q: Can I use it with my laptop or notebook computer?

Answer: Due to their complicated power profile it is not suitable for laptops.

#### Q: What How do I re-enable the Standby Saver?

Answer: Pressing the green button will re-enable the socket.