















































# eTRV: Online Adaptor Guide

| TYPE/MODEL            | IMAGE   | SKETCH  | BASE RINGS/SPACERS   | ADAPTOR   | NOTES  | SECURITY COLLAR? |
|-----------------------|---|---|--|---|--|------------------|
| Comap Western 5 TRV   |    |   |  <p>Three base-ring pegs (3)<br/>3.5mm-thick spacer<br/>28mm base ring</p>                     |   | An extension peg will be needed with this valve, for your eTRV to work. These can be purchased online. |                  |
| Comap Senso TRV       |    |   |  <p>Three base-ring pegs (3)<br/>3.5mm-thick spacer<br/>28mm base ring</p>                     |   | An extension peg will be needed with this valve, for your eTRV to work. These can be purchased online. |                  |
| Comap S2 TRV          |   |   |  <p>Three base-ring pegs (3)<br/>3.5mm-thick spacer<br/>28mm base ring</p>                    |   | An extension peg will be needed with this valve, for your eTRV to work. These can be purchased online. |                  |
| Danfoss RA            |  |  |  <p>Three base-ring pegs (3)<br/>30mm base ring<br/>RA Adaptor</p>                           |   | Both removable and non-removable adaptors are available for purchase online.                           |                  |
| Danfoss RA with screw |  |  |  <p>Three base-ring pegs (3)<br/>30mm base ring<br/>RA Adaptor with Screw</p>                |  | Both removable and non-removable adaptors are available for purchase online.                           | Not Suitable     |
| Danfoss RAV           |  |  |  <p>Three base-ring pegs (3)<br/>30mm base ring<br/>Pin Extension Spacer<br/>RAV Adaptor</p> |  |  | Not Suitable     |
| Danfoss RAL           |   |  |  <p>Three base-ring pegs (3)<br/>30mm base ring<br/>Danfoss RAL Adaptor</p>                  |  |  | Not Suitable     |
| Drayton TRV2          |  |   |  <p>Three base-ring pegs (3)<br/>30mm base ring<br/>TRV2 Adaptor</p>                         |  | This TRV has an imperial thread.   | Not Suitable     |

|                               |  |
|-------------------------------|--|
| <p>Drayton TRV4</p>           |     |
| <p>Giacomini</p>              | <p>Adaptors Available Online</p>   |
| <p>Grasslin Tower TRV REV</p> |    |
| <p>Hattersly 3100 1/2</p>     |  <p>Suitable</p>  |
| <p>Herz 1/2 TS 90</p>         |    |
| <p>Honeywell VT117E</p>       |    |
| <p>Honeywell VT200E</p>       |    |
| <p>Honeywell VT15</p>         |    |
| <p>Myson Petite</p>           |    |
| <p>Myson TRV 2 Way</p>        |    |

|                         |  |  |  |
|-------------------------|--|--|--|
| Oventrop                |  <p><b>Oventrop</b></p> <p>58 mm</p> <p>30 mm</p> |  <p>Three base-ring pegs (3)</p> <p>2mm-thick spacer</p> <p>30mm base ring</p>     |  |
| Pegler Belmont 4        |  |  <p>Three base-ring pegs (3)</p> <p>2mm-thick spacer</p> <p>30mm base ring</p>     |  |
| Pegler Bulldog          |  |  <p>Three base-ring pegs (3)</p> <p>2mm-thick spacer</p> <p>30mm base ring</p>     |  |
| Pegler Mistral          |  |  <p>Three base-ring pegs (3)</p> <p>2mm-thick spacer</p> <p>30mm base ring</p>    |  |
| Pegler Terrier          |  |  <p>Three base-ring pegs (3)</p> <p>2mm-thick spacer</p> <p>30mm base ring</p>   |  |
| PTS Boss Sumpreme       |  |  <p>Three base-ring pegs (3)</p> <p>3.5mm-thick spacer</p> <p>28mm base ring</p> |  |
| Siemens Trade TRV       |  |  <p>Three base-ring pegs (3)</p> <p>2mm-thick spacer</p> <p>30mm base ring</p>   | <p>Adaptors Available Online    This TRV has an imperial thread.</p> |
| Siemens TRV MTN51GB TRV |  |  <p>Three base-ring pegs (3)</p> <p>2mm-thick spacer</p> <p>30mm base ring</p>   |  |
| T+A                     |  <p><b>T+A</b></p> <p>27.5 mm</p> <p>51 mm</p>  |  <p>Three base-ring pegs (3)</p> <p>3.5mm-thick spacer</p> <p>28mm base ring</p> |  |